



ASNU TIPS

65 – 67 Glencoe Road, Bushey, Herts, WD23 3DP UK

Tel: (44) 208 420 4494

E-Mail: enquiries@asnu.com Web: www.asnu.com

(02/2020)

DELPHI MPI Injector – Filter Removal & Re-fit



1. Undo grub screw



2.



3. Delphi Filter Location
(further inside the injector)

4. Re-Fit grub screw using the dimple in the higher position (making the pin stick out further)



5. Use socket (or similar) as a spacer with the ASNU insert tool to fit the filter (filter sits deeper inside the injector)

