



WARNING | WARNING | WARNING

Do not move, change or delete any of the files contained within this ASNU flash drive, they are interconnected and they rely on each of the file interactions to operate. If disrupted it will cease to function.

When loading the USB you may be offered an update for a later version of VLC Media Player.

***** DO NOT UPDATE / DOWNLOAD ANY NEW VERSIONS *****

The VLC Media Player version within the USB is specifically designed for this presentation. and will not work with any other versions!

When you insert your ASNU USB your computer may need to load a new usb driver for this ASNU USB Drive. If this happens wait (approx 1 min) for the notice 'Your device is ready to use' to appear (lower right corner of screen). You may also see a pop up saying your device needs to be scanned and fixed but just press 'Continue without scanning'.

If VLC Media Player is set to autoplay on your device close it and open your 'File Explorer', go to 'This PC', double click to open 'USB Drive', double click on 'Play DVD on PC' and wait for it to load.

Wait around 30 seconds for video to load and the Main Menu to appear. Use either the mouse or keyboard arrow keys to select your desired start point.

The 'DVD Home' symbol button or the 'Skip Backward' button will take you back to the 'Main Menu'.

ASNU Smart TV File

When Smart TV playback is used, chapter functions are not possible.

ASNU Machine Manual Timecodes:

00:00:00 - 00:04:52	Introduction**
00:08:25 - 00:28:06	Presentation**
00:28:07 - 00:29:53	Unpacking the System
00:29:54 - 00:32:35	Setting up & Positioning
00:32:36 - 00:33:55	Safety Precautions
00:33:56 - 00:35:54	System & Safety Precautions
00:35:55 - 00:37:23	Inspection Before Testing
00:37:24 - 00:38:13	Adapters & Harness
00:38:14 - 00:40:15	Mounting the Injectors
00:40:16 - 00:46:24	Test Procedures
00:46:25 - 00:46:48	Emptying Glass Tubes
00:46:49 - 00:48:59	Prep for Ultrasonic Cleaning
00:49:00 - 00:51:20	Ultrasonic Cleaning
00:51:21 - 00:52:42	Replacing Pintle Caps
00:52:43 - 00:56:12	Re-Testing the Injectors
00:56:13 - 01:01:33	Monopoint & TBI Injectors
01:01:34 - 01:04:07	Side Feed Injectors
01:04:08 - 01:05:51	K-Jetronic Injectors
01:05:52 - 01:08:00	Megga Meter
01:08:01 - 01:08:26	Marine & Motorcycle Injectors
01:08:27 - 01:09:09	High Performance Upgrades
01:09:10 - 01:11:09	Machine Functions
01:11:10 - 01:13:52	Machine Maintenance & Service
01:13:53 - 01:14:28	Draining Ultrasonic Fluid
01:14:29 - 01:15:06	Draining Test Fluid

** Please note: if you manually skip these timecodes the 'Menu Chapter' function will not load and the rest of the video will continue to play.

ASNU Corporation Europe Ltd

65-67 Glencoe Road, Bushey, Herts, WD23 3DP, UK

Tel: +44 (0) 208 4204494 | Web: www.asnu.com | Email: enquiries@asnu.com